


Assembly Instructions



Kit includes: (A) Case (B) 2 x Feet (C) 2 x Telescopic upright poles (D) 4 x Top and bottom graphic poles (E) 4 x Thumb screws (F) 2 x Screws (G) 1 x Screwdriver



1 Assemble the telescopic uprights and feet using the supplied screws and driver



2 Align mounting holes to face the flat sides of the feet.



3 Locate and match the top and bottom graphic poles. They are identified by stickers near the shaped ends.



4 Screw each the top and bottom poles to their partner.



5 Attach the bottom pole to one of the upright assemblies, and adjust to the width needed.




6 Attach the top pole to the same upright assembly, and adjust to the width needed.



7 Slid the graphic over the unattached end of the top and bottom poles using the pole pocket.



8 Attach the loose end of the top and bottom graphic poles to the other upright pole.



9 Adjust each of the poles as needed by twisting the locking ring to the left to loosen and right to tighten.