
10X10FT-BOOTH-Y




INSTRUCTION

INSTRUCTION


10X10FT-BOOTH-Y






STEPS

STEP 01 Insert display stands onto feet by pressing their knobs.




STEP 02


Connect to make long poles according to labelings, slide three-way clips onto long poles, insert short curved poles onto their top by pressing their knobs.





Connect long poles and display stand with clamps, adjust their height properly as needed by loosening and tightening screws.





Clip into hanging boards based on directions of three-way clips & tightening with thumb screws, clip F-shaped bar onto hanging board with thumb screws.

STEPS STEP 04 Interconnect display stands with C-shaped clips. ľ 9U **STEP 05** Screw light clips at top of display stands, slide lights onto them and adjust their direction. 0 10X10FT-BOOTH-Y




STEPS

STEP 04

Wrap fabric banner from bottom to top & twist it to be smooth, lay hard case's intermediate panel on podium's top.



INSTRUCTION



STEPS



To Wrap up the fabric banner from top to bottom and zip up.

