


Product Specifications

Graphic Finishing: #2 Grommets in all four corners
Color: Silver
Footprint Dimensions: 10.25 w x 13.75 d
Graphic Templates Available

SKU	Viewable Graphic Size
BSDCP, 210111, 190080	36" x 78"
BSDCP, 210112, 190081	36" x 62"
BSDCP, 210113, 190082	40" x 75"
BSDCP, 210114, 190083	48" x 72"

Product Parts

- 1 - Base
- 2 - Base Receptacle
- 3 - Hubbed Telescoping Pole
- 4 - Hooked Arms (x4)





Display Set-Up

Step 1

Remove all parts from bag and place on a clean, flat surface. Insert the Hubbed Telescoping Pole (3) into the Base Receptacle (2). The pole is secured when the spring lock is engaged with the receptacles slot.



Step 2

Turn the knob on the Hubbed Telescoping Pole (3) counter clockwise to loosen the extending pole. Raise the pole to you desired display height and turn the knob clockwise to lock the extending pole into place.



Step 3

Insert the four Hooked Arms (4) into the 4 holes located on the hub to make an X configuration.



Depending on the size of the banner, you may need to cut the Shock Cord on two or all of the Hooked Arms (4) and remove the Extensions before you place them in the Hub. Keep the extensions as they can be added back on for a larger banner size later.

Step 4

Attach your grommated banner by beginning at the top, insert the four arm hooks into the eyes of the four banner grommets. Poles will bend slightly to keep banner taut. Do not significantly over bend poles, this may cause the poles to break.

